

CS6140 (CS16) Series Lathe
CS6140B (CS16) Series Lathe

Operator's Manual

فروشگاه کانون ابزار

ali5.ir

021 6639 39 00 - 0912 147 30 23

Bochi Machine Tool Group Co.,Ltd.
Baoji Zhongcheng Machine Tool Co.,Ltd.
The People's Republic of China

Notes

1. CS6140 (CS16'') series lathes include the following specifications:

CS6140 (CS16'') CS6240 (CS16''G)

CS6150 (CS20'') CS6250 (CS20''G)

CS6166 (CS26'') CS6266 (CS26''G)

2. CS6140B (CS16B'') series lathe include the following specifications:

CS6140B (CS16'' B) CS6240B (CS16''GB)

CS6150B (CS20'' B) CS6250B (CS20''GB)

CS6166B (CS26'' B) CS6266 B (CS26''GB)

3. This manual is for reference only and its contents are subject to change without notice.

4. Ticked specification is the machine user purchased.

فروشگاه کانون ابزار
all5.ir

021 66393900 - 0912 1473023

Max. swing over bed _____ mm

Max.workpiece length _____ mm

Manufacturing No. _____

Table of contents

1	Safety Instructions.....	1-1
2	Application of machine.....	2-1
3	Technical data.....	3-1
4	Machine drive system.....	4-1
5	Machine operation.....	5-1
6	Electrical part of the machine.....	6-1
7	Lubrication.....	7-1
8	Coolant unit.....	8-1
9	Lifting, installation and test operation.....	9-1
10	Maintenance and care.....	10-1
11	Adjustment and structure.....	11-1
12	Wear parts of the machine and their machining diagrams.....	12-1
13	Standard accessories, tools and optional accessories.....	13-1
14	Foot brake.....	14-1
15	Taper turning attachment.....	15-1
16	Mechanical Feed Stop.....	3

1 Safety Instructions

1.1 General Safety Rules

Operator must read the instructions carefully before operating the machine, and the manager of safety department should assure the operator knows the requirements well.

- 1) The operation, maintenance and repair of the machine must be done by qualified persons who have been trained the ability to forecast the potential risks. Only safety-conscious persons who are fully aware of the risks can operate the machine.
- 2) To those people who assemble, operate, or maintain the machine must be confirmed to have read and understood the operating instructions.
- 3) After stopping the machine, the chuck will still run for a period of time due to inertia, so you need to pay extremely attention to the chuck when you remove the chuck guard and fetch the workpiece.
- 4) Do not detach or modify any safety guard. Be sure that the machine is disconnected from the power when adjusting, maintenance and repair.
- 5) Do not dismantle any safety precaution sign attached to the machine. They should always be kept clean and legible.

WARNING! Never touch the tool or any other driving parts with hands when they are still turning.

- 6) Assign only special persons to operate, maintain and adjust the machine.
- 7) Operate the machine in accordance with technological process. Only qualified persons can completely repair the machine.
- 8) Use standard spanners and pliers for adjustment and repair.
- 9) Stop the machine immediately if an abnormality occurs. Ask for qualified persons to check and repair.
- 10) Dismantle and assembly the machine with the hoisting equipment which is of enough load capacity.
- 11) Observe all safety instructions and warnings attached to the machine; make sure they are always complete and perfectly legible.
- 12) Do safety inspection before operating. Be sure that limit switches for each axis, stop dogs and emergency stop button are all in good condition.
- 13) Reinstalled the removed guards and safety devices in place after maintaining.
- 14) Do maintenance or adjustment only after switch the machine off and remove the plug from the power source outlet, until all moving parts absolutely stop.
- 15) Always keep children away from the machine. Operating personal must be at least 18 years of age.
- 16) Do not wear loose clothing, gloves, neckties or jewelry (rings, watches, etc). Keep the sleeves and the edges of the work uniform tight. Always be sure to wear safety goggles and safety shoes during operation.
- 17) Those with long hair, no matter whether it is a man or woman, should wear safety hat and wrap the hair in

when operating.

- 18) The machine was inspected carefully before shipment from factory. Its noise emission is not higher than 81dB. Wear suitable personal protective equipment when necessary, for instance, wear hearing protection to reduce the risk of induced hearing loss.
- 19) Provide adequate light around the machine, and keep the perimeter around the machine dry, clean and in good order. In addition, do not place anything near the machine; otherwise it becomes an obstacle during operation.
- 20) Do not move away any guard during all working.
- 21) Isolate the machine from the power sources when leaving the machine.
- 22) Restart the machine only after the guards and safety devices are replaced to their position.
- 23) Do not place tools, work-pieces or other items on the machine, especially on the moving parts.
- 24) Do not start the spindle unless the workpiece is clamped completely in the chuck, and the key is taken away from the chuck and the chuck guard is closed.
- 25) When chucking an irregular-shaped workpiece, make some adjustments to center of its gravity so that the workpiece can rotate steadily.
- 26) Stop the machine before adjusting the position of the coolant nozzles.
- 27) Avoid as much as possible, using compressed air to remove dust and chips etc. deposited on the machine, switchboard, NC controller etc.
- 28) The fixtures to be set on the machine must have sufficient rigidity and proper steps should be taken so that the surface of the fixtures will be slip-free.
- 29) Both operators and the maintenance men should read with care the description on the caution plate attached to the machine. They should observe the precautions on this plate during their work. During operation and maintenance, care should be used so that this caution plate is not dirtied or damaged..
- 30) Memorize where the emergency stop push button is so that it can be depressed without delay in case of an emergency.
- 31) Follow the starting procedures given in this manual to start the machine.
- 32) Keep your hands away from the moving parts of the machine during operation.
- 33) Do not get direct access to the work light when it is on. That may cause being scalded.
- 34) Never remove chips from machine during operation. Especially do not handle chips with hands.
- 35) When removing chips caught around the turret or deposited on machine, take them out with a tool instead of hand, because your hand may be injured. Be sure to stop the machine when removing chips from it.
- 36) Prior to starting test operation, carefully read this manual so as to be completely familiar with this machine.
- 37) Contact this company if for some reason the manual should become unreadable.
- 38) When setting up a tool, stop the spindle and the feed in each axis.

1.2 Additional Safety Rules for machine

WARNING! When using electric tools basic safety precautions should always be followed to reduce the risk of fire, electrical shock and personal injury including the following:

Read all these instructions before attempting to operate this product and save these instructions.

- 1) Operating speed of spindle should not exceed permissible speed of chuck (See Operator's Manual of Chuck).
- 2) Do not use a turning tool that is damaged or deformed or unsharp.
- 3) Be sure that the machine is disconnected from the power when adjusting, maintenance and repair.
- 4) Be sure to switch off the machine when performing periodical maintenance or service.
- 5) Release the carriage by loosening the lock screws before moving it longitudinally.
- 6) Add oil or grease to every oil site including guideways, oil cups and 3 cases for ensuring safe and normal operation.
- 7) Use special tools to install turning tool.
- 8) Wear suitable personal protective equipment when necessary, this could include:
 - Eye protection safety goggles
 - Safety hat or headgear for long hair
 - Tight work uniform from head to foot
 - Safety shoes
 - Hearing protection
- 9) When turning a slender **shaft work**, recommend to fasten it with a follow rest, or steady rest or tailstock to prevent it from getting off.
- 10) Put the machine on a solid foundation.
- 11) Never machine flammable materials (like magnesium bar)
- 12) Always use in a well-ventilated area. Remove dust frequently. Clean out dust from the interior to prevent a potential hazard.
- 13) Store idle tools. When not in use, tools should be stored in a dry locked-up place, out of reach of children.
- 14) Keep the cord away from heat, oil and sharp edges.
- 15) Stay alert. Watch what you are doing, use common sense and do not operate the tool when you are tired.
- 16) Inspect the cords and extension cords periodically and if damaged have them repaired or replaced.
- 17) Have the machine repaired by a qualified person. Using of electric tools should comply with the relevant rules.
- 18) Repair of important parts should only be carried out by qualified persons using original spare parts, otherwise

this may result in considerable danger to the user.

- 19) When the machine is used outdoor, use only extension cords intended for outdoor use.
- 20) Recommend to use rust preventive coolant. Important: Coolant must be used in correct ways. Care not to spill it into eyes or onto skin. If do without intention, wash them with plenty of water and go to see a doctor at once.
- 21) Recommend to use refined petrolatum per ISO VG46 (GB/T3141 N46) lubricating the guideways, and to use refined petrolatum per ISO VG32 (GB/T3141 N32) lubricating every cases.
- 22) Hand tools are not allowed to use on the machine.
- 23) When repairing the chuck, please follow the requirements of manufacturer. Make sure that the rated speed of chuck should not be lower than the maximum speed of machine spindle.
- 24) The machine must be checked for balance and alignment after replacement of fixtures.
- 25) Be sure to clamp the workpiece completely and not to leave the wrench on the chuck before starting the machine.
- 26) When turning a long bar , user must protect the part of bar that stretches out of spindle back end using a guard. Remove the guard after completion of machining.
- 27) Irregular-shaped workpieces should be cut at a low speed and in balanced state.
- 28) The machine should be grounded to reduce risk of getting shocked.
- 29) Do not operate the machine in flammable, explosive and damp environment.

WARNING! FAILURE TO FOLLOW THESE RULES MAY RESULT IN SERIOUS PERSONAL INJURY.

WARNING! DO NOT EXPOSE THE MACHINE TO RAIN OR IN DAMP LOCATIONS.

Transport:

Move the machine to a location with lifting hooks or forklift truck. Observe the lifting marks painted on the case when lifting. Lifting can only be started after the case is opened or the skids are removed.

In order to keep balance, move the carriage and tailstock to the extremely right side, and lock them there.

Lift the machine according to Fig. 9-1. Insert a steel bar of 35mm diameter and of 760mm long, and stretch out at least 100mm **away from** every side of machine. When lifting, use wire ropes of 12mm (1/2") diameter. Prevent direct contact between ropes and machine by insertion of wood or used chipboards. Raise and lower the machine carefully, and take special care to prevent impact with any object at the time of lowering. During transporting, the machine should be fastened firmly. The parts easy to be collided should be packed with shock absorption material. The uncovered parts of the machine such as table should be smeared with anti-rust oil.

Installation:

Prepare sufficient space to put the machine and allow safe operation and normal service.

Requirements: Leave at least 600mm between machine back, tailstock and wall. Mount the machine on flat concrete ground and adjust the machine level with gradienter, then fasten it.

For training:

- (1). The operator must be trained for safety and operation before using the machine.
- (2). Be sure to disconnect power supply before making some adjustment and performing service..
- (3). Always wear gloves when handling tools or cutters.

For work-piece guiding the use of:

- (1). The work-piece is possible to be made of the following materials:

- steel
- casting
- copper

- (2). The work-piece is possible to take the following shapes:

- cylindrical
- disk
- pipe
- irregular shape

If the work-piece may affect the process due to unbalance it should be treated additionally. For example, an irregular shaped workpiece can be cut by adding a weight.

WARNING: FAILURE TO FOLLOW THESE RULES MAY RESULT IN SERIOUS PERSONAL INJURY.

1.3 Limitations on ambient conditions

The machine is designed for operating on the site:

- The height above sea level doesn't exceed 1000m;
- The temperature range of air doesn't exceed 5 ~40
- The relative humidity doesn't exceed 50% or 90% at a maximum temperature of +40 or +20 .
- Transportation and storage temperature range is -25 ~+55 .

1.4 Notes on handling Electrical Unit

When operating the machine or performing check and maintenance, observe the following notes.

- (1) Be careful not to touch and jolt the NC controller and the electric circuits.
- (2) Be sure to use a wire or cable of proper length for connecting power supply to the machine. When the power wire or cable inevitably runs across the floor, take adequate measures to protect it against damage from chips etc.
- (3) Do not change the value of current, which has been set with the thermal relay on the distribution board, or other values set previously to various volumes. Use breakers specified in the operation manual for replacement.
- (4) Before checking and maintaining the electrical apparatus, turn off the power switch of the control panel, and the

main switch of the distribution board. In addition, turn off the power switch supplying power from the plant to the machine. Proceed with checks and maintenance only upon confirmation that the power has indeed been cut off. If possible, the power supply should be locked in the off-position during checks and maintenance, or else signs should be posted warning that the maintenance is being performed and no operation is permitted.

- (5) Handle the electrical apparatus of machine with cautions and pay attention to their water proofness.
- (6) An external power supply cable should be prepared by user, which must be larger in diameter than that specified by the manual. Use over voltage protects. Cable in bottom of cabinet should be fixed with cable connector.
- (7) Rated input voltage with fluctuation: 220V/380V/400V/415V/420V/440V/500V/575V/600V/660V ± 10%
- (8) Rated input frequency: 50Hz/60Hz ± 1 Hz
- (9) Phase: 3-phase AC, grounding
- (10) Ambient temperature and humidity should be controlled as steady as possible so that there is no violent change.
- (11) Do not expose the machine as well as the electric unit to environment where corrosive gas or liquid exist such as acid, alkali and salt.
- (12) Do not expose the machine as well as the electric unit to dusty environment. Avoid dust accumulating on any parts of machine.
- (13) Do not expose the machine as well as the electric unit to magnetic or electrostatic environment.

Table of electric data

Rated voltage	Frequency	Phase	Total Current	IP grade
220V	50Hz/60Hz	3	63A	IP54
380V/400V	50Hz/60Hz	3	50A	IP54
415V ~ 660V	50Hz/60Hz	3	40A	IP54

1.5 Safety precaution signs on machine



DANGER

Never touch the parts of machine attached with this sign.




WARNING AND CAUTION

Proper precautions should be taken.



External power cable should be correctly connected to terminals marked by this sign.



Do not operate during turning of spindle.

فروشگاه کانون ابزار

all5.ir

021 6639 39 00 - 0912 147 30 23

2 Application of machine

- 2.1 This lathe in series can perform many operations, such as internal and external turning, taper turning, facing, threading of metric, module and DP threads, drilling, boring and groove broaching.
- 2.2 Gap-bed lathe, additionally, can machine all kinds of flat stocks and those in irregular shapes.
- 2.3 Machining accuracy: circularity deviation less than 0.01 mm, cylindricity deviation not more than 0.02 mm for a measured length of 200 mm, surface finish is excellent.
- 2.4 B series lathe with $\varnothing 82(3\ 15/64)$ thru-bore spindle, can hold bar stocks in larger diameter.
- 2.5 There are inch measure feeding mechanism and metric measure feeding mechanism for users to choose. So it is easy for people from different measure countries to operate.
- 2.6 There are hand brake and foot brake for users to choose.
- 2.7 The lathe operates on power supply of different voltages (220V, 380V, 420V) and different frequencies (50Hz, 60Hz).
- 2.8 The lathe has a wide range of optional accessories for users to select.

3 Technical data

Table 3-1 Technical data

Data Item	Model		CS6140	CS16"	CS6150	CS20"	CS6166	CS26"
			CS6140B	CS16"B	CS6150B	CS20"B	CS6166B	CS26"B
			CS6240	CS16"G	CS6250	CS20"G	CS6266	CS26"G
			CS6240B	CS16"GB	CS6250B	CS20"GB	CS6266B	CS26"GB
Max. swing over bed			? 400(16")		? 500(20")		? 660(26")	
Max. swing over slide			? 220(8")		? 300(12")		? 420(17")	
Max. swing over gap			? 630(25")		? 710(28")		? 870(34")	
Effective length in gap	240(9")							
Max. workpiece length	750/1000/1500/2000/2500/3000(30"/40"/60"/80"/100"/120")							
Max. turning length	700/950/1450/1950/2450/2950(28"/38"/58"/75"/96"/116")							
Spindle thru-hole	? 52(2 3/64") B series ? 82(3 15/64")							
Dia. and taper of spindle bore	MT.No.6 B series ? 90 1:20(3 35/64" 1:20)							
Spindle nose	ISO 702/		No.6 bayonet type B series ISO 702/			No.8 short cam-lock type		
Spindle speeds	24-step 9—1600r/min							
Max. output torque of spindle	1400N.m(1013 lbf.ft)						1200N.m(885 lbf.ft)	
Number and range of long. feeds								
Standard	0.063-2.52mm/r 65 sorts , (0.0023-0.0937in/r,65)							
Decreased	0.028-0.056mm/r 13 sorts, (0.0010-0.0021in/r,13)							
Increased	2.86-6.43mm/r 15 sorts , (0.1064-0.2392in/r,15)							
Number and range of cross feeds								
Standard	0.027-1.07mm/r 65 sorts, (0.0011-0.0404in/r,65)							
Decreased	0.012-0.026mm/r 13 sorts, (0.0004-0.0010in/r,13)							
Increased	1.21-2.73mm/r 15 sorts, (0.0457-0.1032in/r,15)							
Number and range of threading								
Metric threads	0.5-224 48 sorts							
Inch threads	72-1/8tpi 46 sorts							
Module threads	0.5-112 42 sorts							
D.P. threads	56-1/4DP 45 sorts							
Longitudinal rapid traverse	4.5m/min(15ft/min)50Hz				5.4m/min(18ft/min)60Hz			
Cross rapid traverse	1.9m/min(6.37ft/min)50Hz				2.3m/min(7.67ft/min)60Hz			
Pitch of leadscrew	12(2tpi)							
Height of spindle to bearing surface of tool	28(1 3/32")							
Tool section	25mm×25mm(1"×1")							
Swivel angle of fourway tool post	±90°							

Data Item	Model		Model		Model	
	CS6140	CS16"	CS6150	CS20"	CS6166	CS26"
	CS6140B	CS16"B	CS6150B	CS20"B	CS6166B	CS26"B
	CS6240	CS16"G	CS6250	CS20"G	CS6266	CS26"G
	CS6240B	CS16"GB	CS6250B	CS20"GB	CS6266B	CS26"GB
Max. travel of compound rest	145 (5 3/4")					
Max. travel of cross slide	320 (12 5/8")			310 (12 1/8")		
Max. permissible cutting force(Pz)	14000N(3086 lbf)			12000N(2643 lbf)		
Max. permissible feeding force(Px)	3500N (772 lbf)					
Tailstock quill diameter	75(2 61/64")					
Taper of tailstock quill	MT No.5					
Max. travel of quill	150 (5 29/32")					
Cross move of tailstock	± 15 (± 19/32")					
Main motor type, power and speed	Y132M , 7.5kW(10HP) 1450r/min(50Hz) , 1750r/min(60Hz)					
Rapid traverse motor type, power and speed	2AOS , 5632 , 250W(0.34HP) , 1360r/min(50Hz), 1750r/min(60Hz)					
Coolant pump type, power and flow	50L/min(11gal/min)					
V-belt	B2108 4 pieces		B2184 4 pieces		B2337 4 pieces	
Machine net weight						
750(30")	1975kg(4354 lb)		2052kg(4520 lb)		2150kg(4735 lb)	
1000(40")	2050kg(4520 lb)		2100kg(4630 lb)		2200kg(4845 lb)	
1500(60")	2250kg(4960 lb)		2300kg(5070 lb)		2400kg(5286 lb)	
2000(80")	2450kg(5400 lb)		2500kg(5510 lb)		2600kg(5727 lb)	
2500(100")	2650kg(5840 lb)		2700kg(5950 lb)		2800kg(6168 lb)	
3000(120")	2850kg(6280 lb)		2900kg(6390 lb)		3000kg(6610 lb)	
Machine dimensions(Lx Wx H)						
750(30")	2382x 975x 1230		2382x 975x 1270		2382x 975x 1350	
	94"x 38 3/8"x 48 7/16"		94"x 38 3/8"x 50"		94"x 38 3/8"x 53"	
1000(40")	2632x 975x 1230		2632x 975x 1270		2632x 975x 1350	
	104"x 38 3/8"x 48 7/16"		104"x 38 3/8"x 50"		104"x 38 3/8"x 53"	
1500(60")	3132x 975x 1230		3132x 975x 1270		3132x 975x 1350	
	123"x 38 3/8"x 48 7/16"		123"x 38 3/8"x 50"		123"x 38 3/8"x 53"	
2000(80")	3632x 975x 1230		3632x 975x 1270		3632x 975x 1350	
	143"x 38 3/8"x 48 7/16"		143"x 38 3/8"x 50"		143"x 38 3/8"x 53"	
2500(100")	4132x 975x 1230		4132x 975x 1270		4132x 975x 1350	
	163"x 38 3/8"x 48 7/16"		163"x 38 3/8"x 50"		163"x 38 3/8"x 53"	
3000(120")	4632x 975x 1230		4632x 975x 1270		4632x 975x 1350	
	183"x 38 3/8"x 48 7/16"		183"x 38 3/8"x 50"		183"x 38 3/8"x 53"	

فروشگاه کانون ابزار

ali5.ir

021 6639 3900 = 0912 147 3023

4 Machine drive system

4.1 Tables and diagrams

Fig.4-1 shows the machine's drive system. Table 4-1 lists all the metric parts while Table 4-2 lists all the inch parts. Every bearing in drive system is listed in Table 4-3 and their positions are illustrated in Fig. 4-2.




Fig. 4-1 Drive system diagram

Right handwheel drive system diagram




Fig. 4-2 Bearing location diagram

Table 4-1 List of metric drive parts

Name	No.	Part No.	No.of teeth or starts	Module or pitch	Position change ratio or start dir.	Helix / profile angle	Material	Heat treat-ment														
Head-stock	1	02081	45	2.5		20°	45	G48														
	2	02082	45				40Cr	G52														
	3	02083	40																			
	4	02084	36																			
	5	02085	28																			
	6	02086	32																			
	7	02106	48						45	G48												
	8	02087	32						40Cr	G52												
	9	02089	36																			
	10	02091	44																			
	11	02088	40																			
	12	02092	36																			
	13	02092	20																			
	14	02105	32								+0.525	45	G48									
	15	02093	45	40Cr	G52																	
	16	02094	61																			
	17	02095	30			3	Left	20°/13°10"			45	G48										
	18	02095	17																			
	19	02096	48																			
	20	02056	16																			
	21	02097	17										Right	L+0.5868	40Cr	G48						
	22	02098	60																			
	23	02099	20																			
	24	*B02104	48						20°	20°/13°10"							45	G48				
	25	*B02102	40																			
	26	*B02101	80																			
	27	02114	32																2.5	20°	40Cr	G48
	28	02103	26																			
	29	02107	48																			
	30	02108	31																			
	31	02108	31	R-0.5868	45	G48																
	32	02111	18																			
	33	02109	31																			

To continue from the above table 4-1

Name	No.	Part No.	No.of teeth or starts	Module or pitch	Position change ratio or start dir.	Helix / profile angle	Material	Heat treatment
Change gear	34	08042	60	? 2 /2.25 /2.75		20°	45	
	35	08043	69				Nylon MC	
	36	08041	56				45	
	37	08044	57					
Feeding case	38	07061	28	2.25	+0.6	20°	45	G42
	39	07061	30	1.75				
	40	07062	27	2.25	-0.1323			
	41	07063	41	1.75	+0.5254			
	42	07064	30	2.25	-0.3323			
	43	07064	29	1.75	+0.5731			
	44	07066	21	3	+0.50			
	45	07066	28	2	+0.30			
	46	07073	20	3	+0.04256			
	47	07072	118		+0.1352			
	48	07071	21		-0.50			
	49	07069	36	2	+0.7687			
	50	07068	32		+1.444			
	51	07067	33		+0.8117			
	52	07065	30	1.75				
	53	07066	21	3	+0.50			
	54	07066	28	2	+0.30			
	55	07032	14	2.25	+0.40			
	56	07032	22		-0.40			
	57	07076	42		+0.1323			
	58	07077	33		+0.5324			
	59	07078	15					
	60	07079	24					
	61	07074	22	2	+0.40			
62	07074	40						
63	07074	32						
64	07075	21						
65	07034	21	+0.25					
66	07038	42	-0.25					

To continue from the above table 4-1

Name	No.	Part No.	No.of teeth or starts	Module or pitch	Position change ratio or start dir.	Helix / profile angle	Material	Heat treatment
Apron	67	06061	36	1.5		20°	40Cr	
	68	06062	32				45	
	69	06063	56				GCr15	
	70	06057	2	2.5	Left	6°20'25"	45	
	71	06021	26			6°20'25"	ZcuSn10Pb1	
	72	06064	32	1.75		20°	45	G48
	73	06065	36		45			
	74	06065	36	1.75	Left	20°	45	G48
	75	06066	45				40Cr	
	76	06066	45					
	77	06069	87	2.5036	+0.249		45	
	78	06052	12					
	79	01024	Rack	1.75			45	
	80	06071	18					
	81	06072	28	1.5			45	
	82	06073	20					
	83	06074	89	1.75			40Cr	
	84	06066	45					G48
	85	06066						
86	06067	35	12			45	G48	
87	06068	58				ZcuSn10Pb1		
88	06022	1				Y40Mn		
89	01021							
RH apron	79	01024A		2.5036		20°	45	G48
	89	01021A		12	Y40Mn			
	70	06057A	2	2.5	Left	6°20'25"	45	
	78	06052A	12	2.5036	+0.049	20°		
Tool post	90	05031	18	1.75	Left		40Cr	D0.3-550
	91	05021	1	5			Y40Mn	
	92	05011					HT200	
	93	04011						
94	04031	Y40Mn						
Tail-stock	95	03022					Y40Mn	
	96	03005					HT150	
Pulley	97	15002	? 115	B type			HT150	
		15002/60Hz	? 93					
	98	02003	? 175					

Table 4-2 List of inch drive parts

Name	No.	Part No.	No.of teeth or starts	Module or pitch	Position change ratio or start dir.	Helix / profile angle	Material	Heat treatment
Change gear	34	08042Y	82	1.5/2.25		20°	45	
	35	08043Y	57					
	36	08041Y	81					
	37	08044Y	69					
Apron	81	06072Y	30	1.5		20°	45	
	82	06073Y	28					
	83	06074Y	97					
	88	06022Y	1	12.7			ZcuSn10Pb1	
	89	01021Y					Y40Mn	
Tool post	91	05021Y	1	5.08			Y40Mn	
	92	05011Y					ZcuSn10Pb1	
	93	04011Y					HT200	
	94	04031Y					Y40Mn	
Note: Part No. of CS6140B series are marked by asterisk *.								

Table 4-3 Bearing location

Type	Specification	Qty.	Number on diagram
7000106	35x55x9	2	44 , 45
105	25x47x12	10	1 , 8 , 14 , 15 , 16 , 17 , 31 , 37 , 40 , 41
106	30x55x13	1	25
203	17x40x12	9	29 , 30 , 33 , 34 , 35 , 36 , 38 , 39 , 46
205	25x52x15	3	13 , 24 , 32
208	40x80x18	3	12 , 18 , 19
303	17x47x14	1	27
304	20x52x15	1	28
305	25x62x17	3	26 , 20 , 10
306	30x72x19	2	21 , 11
307	35x80x21	2	9 , 5
308	40x90x23	1	22
D119	95x145x24	1	23(B series)
1D3182120	100x150x37	1	6(B series)
1D3182124K	120x180x46	1	2(B series)
7205E	25x52x16.5	2	47 , 48
7209E	45x85x21	1	7
7608E	40x90x35.5	1	4
D8106	30x47x11	2	42 , 43
5D2268124	120x150x25	1	3(B series)
8205	25x47x15	1	49
17	7x19x6	4	50 , 51
D215	75x130x25	1	23
D3182116	80x125x34	1	6
1D3182120K	100x150x37	1	2
5D2268120	100x150x60		3

5 Machine operation

5.1 Controls

Fig.5-1 shows the location and function of controls on machine.

5.2 Method

5.2.1 Drive system

Different spindle speeds are available by setting spindle speed shifting levers (8) and (10). For CS6266B lathe, different spindle speeds are available by setting spindle speed shifting levers (2) and (3).





24-step spindle speeds of clockwise or counter-clockwise are gotten if Lever (8) is set to one of its 8 positions and Lever (10) to a position with the same color as that of Lever (8). For CS6266B lathe, 24-step spindle speeds of clockwise or counter-clockwise are gotten if Lever (2) is set to one of its 8 positions and Lever (3) to a position with the same color as that of Lever (2). See Table 5-1.

When Lever (10) is set to the neutral (white) position the spindle will disengage from other driving shafts and stop rotating. For CS6266B lathe, when Lever (3) is set to the neutral (white) position the spindle will disengage from other driving shafts and stop rotating. Feed motion also stops at the same time but it can be activated by using the increased pitch mechanism.


5.2.2 Feed system

5.2.2.1 Setting the pitch and feed: Different pitches and feeds are available by setting lever (6) on headstock, control knob (7), (9) and (11) on feeding case. For CS6266B lathe, different pitches and feeds are available by setting lever (1) on headstock, control knob (5), (6) and (7) on feeding case.

a) Feed selector lever (6) is used to change pitch of threads and helix direction, or to change feeds. Because of a single-direction overrunning clutch fixed in the apron, feed motion is impossible unless lever (6) is set to RIGHT-HAND position. For CS6266B lathe, Feed selector lever (1) is used to change pitch of threads and helix direction, or to change feeds. Because of a single-direction overrunning clutch fixed in the apron, feed motion is impossible unless lever (1) is set to RIGHT-HAND position.

	Right-hand thread with normal pitch. Feed is available.
	Left-hand thread with normal pitch. No feed.
	Right-hand thread with increased pitch. Reduced or increased feed.
	Left-hand threads with increased pitch. No feed.

b) Thread selector (7) is designed to select type of threads and also can be used to change feeds. For CS6266B lathe, Thread selector (5) is designed to select type of threads and also can be used to change feeds.

t	Metric thread
n	Inch thread
m	Module thread
DP	Diametral pitch thread
	Neutral

c) Pitch and feed control knob (9) is used to change pitch and feed in an order from 1 to 15 as indicated on the data plate. For CS6266B lathe, pitch and feed control knob (6) is used to change pitch and feed in an order from 1 to 15 as indicated on the data plate.

d) Pitch and feed knob (11) is used to multiply the pitch and feed by means of lead screw and feed rod. For CS6266B lathe, pitch and feed (7) is used to multiply the pitch and feed by means of lead screw and feed rod.

、 、 、 : Lead screw is engaged to cut a thread.

A、 B、 C、 D : Feed rod is engaged to give a feed motion.

Ratio : : : =A:B: C: D=1:2:4:8

By setting the above levers and knobs accordingly different feeds listed in Table 5-2 are obtained. To ensure good operating of machine setting levers and knobs should be based upon the principle that a higher spindle speed matches a finer feed, and vice versa.

The leadscrew can be driven directly by shaft through change gears in stead of externally engaged gears in feeding case in order to cut threads excluded in Table 5-2. To do so, thread selector (7) must be set to NEUTRAL position and pitch and feed knob (11) to position. For CS6266B lathe, to do so, thread selector (5) must be set to NEUTRAL position and pitch and feed knob (7) to position.


5.2.2.2 Carriage operation

a) Feed axis selector and rapid traverse button (21) is used to move the carriage or rapidly traverse it in the direction it is set. For CS6266B lathe, feed axis selector and rapid traverse button (13) is used to move the carriage or rapidly traverse it in the direction it is set. To rapidly traverse the button on head of the lever should be pressed and held till the carriage moves to the desired position.

b) Half nut lever (18) is used to move the carriage back and forth along the bed when cutting threads. The half nut is closed when lever (18) is turned clockwise and separated when lever (18) is turned counter-clockwise. For CS6266B lathe, half nut lever (8) is used to move the carriage back and forth along the bed when cutting threads. The half nut is closed when lever (8) is turned clockwise and separated when lever (8) is turned counter-clockwise.


c) Apron hand-wheel (13), cross slide handle (14) and compound rest handle (20) are all manual controls. Each of them has a dial on its base to indicate distance moved. For CS6266B lathe, apron hand-wheel (11), cross slide handle (9) and compound rest handle (19) are all manual controls. Each of them has a dial on its base to indicate distance moved.

5.2.2.3 For other controls, see the operation diagram. When spindle control lever (12) is put to the upper position, the spindle starts to run forward; when it is put to the lower position the spindle starts to run backward; when it is put to the middle position the spindle stops.



- | | |
|-----------------------------------|---|
| (1) Coolant supply ON/OFF button | (14) Cross slide handle |
| (2) Emergency stop button | (15) Tool post lever |
| (3) Main motor start button | (16) Work lamp switch |
| (4) Power switch | (17) Main motor control button |
| (5) End cover lever | (18) Half nut lever |
| (6) Feed selector lever | (19) Spindle control lever |
| (7) Thread selector | (20) Compound rest handle |
| (8) Spindle speed shifting lever | (21) Feed axis selector and rapid traverse button |
| (9) Pitch and feed control knob | (22) Coolant flow faucet |
| (10) Spindle speed shifting lever | (23) Tailstock quill lock lever |
| (11) Pitch and feed knob | (24) Tailstock clamping lever |
| (12) Spindle control lever | (25) Tailstock handwheel |
| (13) Apron handwheel | |

Fig. 5-1a Location and function of controls



- | | |
|----------------------------------|---|
| (1) Feed selector lever | (13) Feed axis selector and rapid traverse button |
| (2) Spindle speed shifting lever | (14) Mechanical feed stop selection lever |
| (3) Spindle speed shifting lever | (15) Tailstock handwheel |
| (4) End cover lever | (16) Tailstock clamping lever |
| (5) Thread selector | (17) Tailstock quill speed control knob |
| (6) Pitch and feed control knob | (18) Tailstock quill lock lever |
| (7) Pitch and feed knob | (19) Compound rest handle |
| (8) Half nut lever | (20) Tool post lever |
| (9) Cross slide handle | (21) Power switch |
| (10) Lube pump | (22) Emergency stop button |
| (11) Apron handwheel | (23) Coolant supply ON button |
| (12) Spindle control lever | (24) Coolant supply OFF button |

Fig. 5-1b Location and function of controls of CS6266B

Table 5-1 Spindle speeds







No	Lever position		Spindle speeds r/min			Drive efficiency	Permissible load		Weak point	Times enlarged	
	10	8	Normal	Calculated			Output power kW	Max. torque N·m			
				CW	CCW						
1	 Blue	1	 Blue	9	9.06	9.2	0.773	5.8	1400	Gear 13 (Fig.1)	16:1
2		2		11	11.4	11.6					
3		3		14	14.2	14.4					
4		4		18	17.8	18.1					
5		5		22	22.1	22.4					
6		6		28	27.8	28.2					
7		7		35	34.7	35.2					
8		8		45	43.4	44.1					
9	 Yellow	1	 Yellow	55	54.4	55.2	0.797	6.0	1039	Friction clutch	8:3
10		2		70	68.3	69.4					
11		3		85	85.4	86.7					
12		4		105	106.8	108.5					
13		5		132	132.6	134.7					
14		6		170	166.7	169.3					
15		7		210	208.4	211.7					
16		8		260	260.5	264.6					
17	 Red	1	 Red	320	326.1	331.2	0.797	6.0	185	Friction clutch	4:9
18		2		400	410.1	416.5					
19		3		500	512.5	520.5					
20		4		630	640.6	650.6					
21		5		800	795.8	808.2					
22		6		1160	1000.4	1016.0					
23		7		1250	1250.5	1270.0					
24		8		1600	1563.1	1587.5					

Table 5-2b Feeds and pitches (Applicable to CS6¹₂ 66(B) lathe)

Metric

A	mm				mm				mm				mm				mm				DP/1"	DP	DP/1"	DP																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																				
	A	B	C	D	A	B	C	D	A	B	C	D	A	B	C	D	A	B	C	D																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																								
0.076	0.083	0.09	0.10	0.11	0.12	0.13	0.14	0.15	0.16	0.17	0.18	0.19	0.20	0.21	0.22	0.23	0.24	0.25	0.26	0.27	0.28	0.29	0.30	0.31	0.32	0.33	0.34	0.35	0.36	0.37	0.38	0.39	0.40	0.41	0.42	0.43	0.44	0.45	0.46	0.47	0.48	0.49	0.50	0.51	0.52	0.53	0.54	0.55	0.56	0.57	0.58	0.59	0.60	0.61	0.62	0.63	0.64	0.65	0.66	0.67	0.68	0.69	0.70	0.71	0.72	0.73	0.74	0.75	0.76	0.77	0.78	0.79	0.80	0.81	0.82	0.83	0.84	0.85	0.86	0.87	0.88	0.89	0.90	0.91	0.92	0.93	0.94	0.95	0.96	0.97	0.98	0.99	1.00	1.01	1.02	1.03	1.04	1.05	1.06	1.07	1.08	1.09	1.10	1.11	1.12	1.13	1.14	1.15	1.16	1.17	1.18	1.19	1.20	1.21	1.22	1.23	1.24	1.25	1.26	1.27	1.28	1.29	1.30	1.31	1.32	1.33	1.34	1.35	1.36	1.37	1.38	1.39	1.40	1.41	1.42	1.43	1.44	1.45	1.46	1.47	1.48	1.49	1.50	1.51	1.52	1.53	1.54	1.55	1.56	1.57	1.58	1.59	1.60	1.61	1.62	1.63	1.64	1.65	1.66	1.67	1.68	1.69	1.70	1.71	1.72	1.73	1.74	1.75	1.76	1.77	1.78	1.79	1.80	1.81	1.82	1.83	1.84	1.85	1.86	1.87	1.88	1.89	1.90	1.91	1.92	1.93	1.94	1.95	1.96	1.97	1.98	1.99	2.00	2.01	2.02	2.03	2.04	2.05	2.06	2.07	2.08	2.09	2.10	2.11	2.12	2.13	2.14	2.15	2.16	2.17	2.18	2.19	2.20	2.21	2.22	2.23	2.24	2.25	2.26	2.27	2.28	2.29	2.30	2.31	2.32	2.33	2.34	2.35	2.36	2.37	2.38	2.39	2.40	2.41	2.42	2.43	2.44	2.45	2.46	2.47	2.48	2.49	2.50	2.51	2.52	2.53	2.54	2.55	2.56	2.57	2.58	2.59	2.60	2.61	2.62	2.63	2.64	2.65	2.66	2.67	2.68	2.69	2.70	2.71	2.72	2.73	2.74	2.75	2.76	2.77	2.78	2.79	2.80	2.81	2.82	2.83	2.84	2.85	2.86	2.87	2.88	2.89	2.90	2.91	2.92	2.93	2.94	2.95	2.96	2.97	2.98	2.99	3.00	3.01	3.02	3.03	3.04	3.05	3.06	3.07	3.08	3.09	3.10	3.11	3.12	3.13	3.14	3.15	3.16	3.17	3.18	3.19	3.20	3.21	3.22	3.23	3.24	3.25	3.26	3.27	3.28	3.29	3.30	3.31	3.32	3.33	3.34	3.35	3.36	3.37	3.38	3.39	3.40	3.41	3.42	3.43	3.44	3.45	3.46	3.47	3.48	3.49	3.50	3.51	3.52	3.53	3.54	3.55	3.56	3.57	3.58	3.59	3.60	3.61	3.62	3.63	3.64	3.65	3.66	3.67	3.68	3.69	3.70	3.71	3.72	3.73	3.74	3.75	3.76	3.77	3.78	3.79	3.80	3.81	3.82	3.83	3.84	3.85	3.86	3.87	3.88	3.89	3.90	3.91	3.92	3.93	3.94	3.95	3.96	3.97	3.98	3.99	4.00	4.01	4.02	4.03	4.04	4.05	4.06	4.07	4.08	4.09	4.10	4.11	4.12	4.13	4.14	4.15	4.16	4.17	4.18	4.19	4.20	4.21	4.22	4.23	4.24	4.25	4.26	4.27	4.28	4.29	4.30	4.31	4.32	4.33	4.34	4.35	4.36	4.37	4.38	4.39	4.40	4.41	4.42	4.43	4.44	4.45	4.46	4.47	4.48	4.49	4.50	4.51	4.52	4.53	4.54	4.55	4.56	4.57	4.58	4.59	4.60	4.61	4.62	4.63	4.64	4.65	4.66	4.67	4.68	4.69	4.70	4.71	4.72	4.73	4.74	4.75	4.76	4.77	4.78	4.79	4.80	4.81	4.82	4.83	4.84	4.85	4.86	4.87	4.88	4.89	4.90	4.91	4.92	4.93	4.94	4.95	4.96	4.97	4.98	4.99	5.00	5.01	5.02	5.03	5.04	5.05	5.06	5.07	5.08	5.09	5.10	5.11	5.12	5.13	5.14	5.15	5.16	5.17	5.18	5.19	5.20	5.21	5.22	5.23	5.24	5.25	5.26	5.27	5.28	5.29	5.30	5.31	5.32	5.33	5.34	5.35	5.36	5.37	5.38	5.39	5.40	5.41	5.42	5.43	5.44	5.45	5.46	5.47	5.48	5.49	5.50	5.51	5.52	5.53	5.54	5.55	5.56	5.57	5.58	5.59	5.60	5.61	5.62	5.63	5.64	5.65	5.66	5.67	5.68	5.69	5.70	5.71	5.72	5.73	5.74	5.75	5.76	5.77	5.78	5.79	5.80	5.81	5.82	5.83	5.84	5.85	5.86	5.87	5.88	5.89	5.90	5.91	5.92	5.93	5.94	5.95	5.96	5.97	5.98	5.99	6.00	6.01	6.02	6.03	6.04	6.05	6.06	6.07	6.08	6.09	6.10	6.11	6.12	6.13	6.14	6.15	6.16	6.17	6.18	6.19	6.20	6.21	6.22	6.23	6.24	6.25	6.26	6.27	6.28	6.29	6.30	6.31	6.32	6.33	6.34	6.35	6.36	6.37	6.38	6.39	6.40	6.41	6.42	6.43	6.44	6.45	6.46	6.47	6.48	6.49	6.50	6.51	6.52	6.53	6.54	6.55	6.56	6.57	6.58	6.59	6.60	6.61	6.62	6.63	6.64	6.65	6.66	6.67	6.68	6.69	6.70	6.71	6.72	6.73	6.74	6.75	6.76	6.77	6.78	6.79	6.80	6.81	6.82	6.83	6.84	6.85	6.86	6.87	6.88	6.89	6.90	6.91	6.92	6.93	6.94	6.95	6.96	6.97	6.98	6.99	7.00	7.01	7.02	7.03	7.04	7.05	7.06	7.07	7.08	7.09	7.10	7.11	7.12	7.13	7.14	7.15	7.16	7.17	7.18	7.19	7.20	7.21	7.22	7.23	7.24	7.25	7.26	7.27	7.28	7.29	7.30	7.31	7.32	7.33	7.34	7.35	7.36	7.37	7.38	7.39	7.40	7.41	7.42	7.43	7.44	7.45	7.46	7.47	7.48	7.49	7.50	7.51	7.52	7.53	7.54	7.55	7.56	7.57	7.58	7.59	7.60	7.61	7.62	7.63	7.64	7.65	7.66	7.67	7.68	7.69	7.70	7.71	7.72	7.73	7.74	7.75	7.76	7.77	7.78	7.79	7.80	7.81	7.82	7.83	7.84	7.85	7.86	7.87	7.88	7.89	7.90	7.91	7.92	7.93	7.94	7.95	7.96	7.97	7.98	7.99	8.00	8.01	8.02	8.03	8.04	8.05	8.06	8.07	8.08	8.09	8.10	8.11	8.12	8.13	8.14	8.15	8.16	8.17	8.18	8.19	8.20	8.21	8.22	8.23	8.24	8.25	8.26	8.27	8.28	8.29	8.30	8.31	8.32	8.33	8.34	8.35	8.36	8.37	8.38	8.39	8.40	8.41	8.42	8.43	8.44	8.45	8.46	8.47	8.48	8.49	8.50	8.51	8.52	8.53	8.54	8.55	8.56	8.57	8.58	8.59	8.60	8.61	8.62	8.63	8.64	8.65	8.66	8.67	8.68	8.69	8.70	8.71	8.72	8.73	8.74	8.75	8.76	8.77	8.78	8.79	8.80	8.81	8.82	8.83	8.84	8.85	8.86	8.87	8.88	8.89	8.90	8.91	8.92	8.93	8.94	8.95	8.96	8.97	8.98	8.99	9.00	9.01	9.02	9.03	9.04	9.05	9.06	9.07	9.08	9.09	9.10	9.11	9.12	9.13	9.14	9.15	9.16	9.17	9.18	9.19	9.20	9.21	9.22	9.23	9.24	9.25	9.26	9.27	9.28	9.29	9.30	9.31	9.32	9.33	9.34	9.35	9.36	9.37	9.38	9.39	9.40	9.41	9.42	9.43	9.44	9.45	9.46	9.47	9.48	9.49	9.50	9.51	9.52	9.53	9.54	9.55	9.56	9.57	9.58	9.59	9.60	9.61	9.62	9.63	9.64	9.65	9.66	9.67	9.68	9.69	9.70	9.71	9.72	9.73	9.74	9.75	9.76	9.77	9.78	9.79	9.80	9.81	9.82	9.83	9.84	9.85	9.86	9.87	9.88	9.89	9.90	9.91	9.92	9.93	9.94	9.95	9.96	9.97	9.98	9.99	10.00	10.01	10.02	10.03	10.04	10.05	10.06	10.07	10.08	10.09	10.10	10.11	10.12	10.13	10.14	10.15	10.16	10.17	10.18	10.19	10.20	10.21	10.22	10.23	10.24	10.25	10.26	10.27	10.28	10.29	10.30	10.31	10.32	10.33	10.34	10.35	10.36	10.37	10.38	10.39	10.40	10.41	10.42	10.43	10.44	10.45	10.46	10.47	10.48	10.49	10.50	10.51	10.52	10.53	10.54	10.55	10.56	10.57	10.58	10.59	10.60	10.61	10.62	10.63	10.64	10.65	10.66	10.67	10.68	10.69	10.70	10.71	10.72	10.73	10.74	10.75	10.76	10.77	10.78	10.79	10.80	10.81	10.82	10.83	10.84	10.85	10.86	10.87	10.88	10.89	10.90	10.91	10.92	10.93	10.94	10.95	10.96	10.97	10.98	10.99	11.00	11.01	11.02	11.03	11.04	11.05	11.06	11.07	11.08	11.09	11.10	11.11	11.12	11.13	11.14	11.15	11.16	11.17	11.18	11.19	11.20	11.21	11.22	11.23	11.24	11.25	11.26	11.27	11.28	11.29	11.30	11.31	11.32	11.33	11.34	11.35	11.36	11.37	11.38	11.39	11.40	11.41	11.42	11.43	11.44	11.45	11.46	11.47	11.48	11.49	11.50	11.51	11.52	11.53	11.54	11.55	11.56	11.57	11.58	11.59	11.60	11.61	11.62	11.63	11.64	11.65	11.66	11.67	11.68	11.69	11.70	11.71	11.72	11.73	11.74	11.75	11.76	11.77	11.78	11.79	11.80	11.81	11.82	11.83	11.84	11.85	11.86	11.87	11.88	11.89	11.90	11.91	11.92	11.93	11.94	11.95	11.96	11.97	11.98	11.99	12.00	12.01	12.02	12.03	12.04	12.05	12.06	12.07	12.08	12.09	12.10	12.11	12.12	12.13	12.14	12.15	12.16	12.17	12.18	12.19	12.20	12.21	12.22	12.23	12.24	12.25	12.26	12.27	12.28	12.29	12.30	12.31	12.32	12.33	12.34	12.35	12.36	12.37	12.38	12.39	12.40	12.41	12.42	12.43	12.44	12.45	12.46	12.47	12.48	12.49	12.50	12.51	12.52	12.53	12.54	12.55	12.56	12.57	12.58	12.59	12.60	12.61	12.62	12.63	12.64	12.65	12.66	12.67	12.68	12.69	12.70	12.71	12.72	12.73	12.74	12.75	12.76	12.77	12.78	12.79	12.80	12.81	12.82	12.83	12.84	12.85	12.86	12.87	12.88	12.89	12.90	12.91	12.92	12.93	12.94	12.95	12.96	12.97	12.98	12.

6 Electrical part of the machine

6.1 Preparation before applying power source

After installation, following checks must be taken to guarantee safe operation.

1) Observation check. Open the door of cabinet and make sure that no element inside is damaged. Make sure that every connector and wires are connected firmly.

2) Be sure that no water has come into the cabinet and it is dry inside.

3) Measure the power supply with a multimeter and be sure it is the required specifications.

6.2 Operation and wire connection

Fig.6-1 is parts location diagram. Fig.6-2 is electric schematic diagram. Fig.6-3 is wire connection diagram. Table 6-1 lists all electrical parts.

The machine operates on power source of 3-phase AC 220V, 380V, 400V, 415V, 420V, 440V, 500V, 575V, 600V, 660V, and 50Hz/60Hz, There is no general fuse on the machine, so user should connect a desired fuse to the power source circuit. CS6266B lathe has power light and coolant light.

Connect the power line to the terminal board, which is installed in the front support of the machine and accessed through the window at rear side of the support. Connect and fasten the ground wire to the earth screw.

Supply electric power for machine by closing the power switch QS1. Lamp EL is lit up.

The motor starts to run when SB3 or SB4 is pushed and stops when SB2 or SB5 is pushed.

Coolant pump M2 is unable to be started unless the motor is running. Coolant pump is started using SB6 and stops as the motor stops.

Work lamp EL is turned on and off with switch SA1 on condition that power switch QS1 is closed.

Limit switch SQ1 breaks the related contacts and cuts power from motor and from electric control unit to ensure safety of service man when the change gears cover is opened for maintenance and adjustment.

The electric parts can not be accessed unless the second protection door, which is installed to avoid accidental touch of electric parts, is removed. SQ5 is a door trip and is used to disconnect control circuit.

The right to change the data of this part for meeting customers' requirement is reserved.





Fig.6-1a Location of electrical parts



Code	Description	Code	Description	Code	Description	Code	Description
QS1	Power isolating switch	EL	Work lamp	SB7	Coolant stop switch	XT1	Terminals
SQ1	Change gear cover switch	SB1	Jogging button	SB8	E.stop switch	XT2	Terminals
SQ2	Foot brake switch	SB2	Spindle stop button	M1	Spindle motor	XT3	Terminals
SQ3	Vertical shaft switch	SB3	Spindle start button	M2	Coolant pump motor	XT4	Terminals
SQ4	Chuck protect switch	SB4	Spindle start button	M3	Rapid traverse motor	XT5	Terminals
SQ5	Door trip	SB5	E.stop switch	HL1	Power ON light		
SQ6	Tool post protect switch	SB6	Coolant start switch	HL2	Coolant ON light		

Note:

1. XT5 is provided for right-hand apron machine only.
2. M3 is located in the right of apron in case of a left-hand apron machine.
3. Those marked by * are optional parts.

Fig.6-1b Location of electrical parts of CS6266B




Fig. 6-2a Electric schematic diagram (1)




Fig. 6-2a Electric schematic diagram (2)




Fig. 6-2b Electric schematic diagram of CS6266B (1)






Fig. 6-2b Electric schematic diagram of CS6266B (2)



- Note: 1. All wire section refers to the copper wire only.
 2. Those marked by * are optional parts.
 3. Number of wire 6 of SB5 is changed to 26 when SB8 is provided.
 Number of wire 9 of SQ4 is changed to 29 when SQ5 is provided.

Fig. 6-3a Electric connection diagram



Note: 1. All wire section refers to the copper wire only.

- 2. Those marked by * are optional parts.
- 3. Number of wire 6 of SB5 is changed to 26 when SB8 is provided.
Number of wire 9 of SB4 is changed to 29 when SB6 is provided.

Fig. 6-3b Electric connection diagram of CS6266B

Table 6-1 List of electrical parts

Code	Name	Specification	Qty	Maker	Remark
QS1	Power switch	3-pole Ue=660V ~ Ie=40A	1	Beijing Machine Tool Switchgear Co., Ltd.	
FU1	Fuse	Ue=380V ~ 4A	3	Suzhou Stone Electrical Appliance Factory	3 ~ 380V
		6A	3		3 ~ 220V
FU1		Ue=500V ~ 4A	3		3 ~ 420V/660V
FU2 FU3 FU4		2A	1		
KM1	Contactor	3-pole Ue=380V ~ Coil 1 ~ 50/60Hz 220V/24V/110V Ie=18A/AC3 3P+NO	1	Tianshui 213 Electrical Apparatus Co., Ltd.	3 ~ 380V
		3-pole Ue=220V ~ Coil 1 ~ 50/60Hz 220V/24V/110V Ie=32A/AC3A 3P+NO			3 ~ 220V
		3-pole Ue=660V ~ Coil 1 ~ 50/60Hz 220V/24V/110V Ie=18A/AC3 3P+NO			3 ~ 420V/660V
KM2 KM3		3-pole Ue=380V ~ Coil 1 ~ 50/60Hz 220V/24V/110V Ie=9A/AC3 3P+NO	1		3 ~ 380V/220V
KM2 KM3		3-pole Ue=380V ~ Coil 1 ~ 50/60Hz 220V/24V/110V Ie=9A/AC3 3P+NO	1		3 ~ 420V/600V
FR1	Thermal relay	Current/rated 23 ~ 32A 12 ~ 18A 10 ~ 13A	1 1 1	Tianshui 213 Electrical Apparatus Co., Ltd.	3 ~ 220V 3 ~ 380V/440V 3 ~ 500V /660V
FR2	Thermal relay	Current/rated 0.4 ~ 0.63A 0.25 ~ 0.4A 0.16 ~ 0.25A	1 1 1		3 ~ 220V 3 ~ 380V/420V 3 ~ 440V /660V

Code	Name	Specification	Qty	Maker	Remark
FR3	Thermal relay	Current/rated			250W motor 3 ~ 220V 3 ~ 380V/440V 3 ~ 500V /660V
		2.5 ~ 4A	1		
		1 ~ 1.6A	1		
FR3	Thermal relay	Current/rated		Tianshui 213 Electrical Apparatus Co., Ltd.	300W motor 3 ~ 220V 3 ~ 380V/400V 3 ~ 415V /500V 3 ~ 575V /660V
		2.5 ~ 4A	1		
		1.6 ~ 2.5A	1		
		1 ~ 1.6A	1		
FR3	Thermal relay	Current/rated			370W motor 3 ~ 220V 3 ~ 380V/440V 3 ~ 500V /660V
		2.5 ~ 4A	1		
		1.6 ~ 2.5A	1		
SB1	Rapid traverse button,	Ue=380V ~ Ie=5A 1 No black 1 NC red	1	Changsha No.2 Machine Electrical Equipment Factory	
	SB5		Emergency stop button	1	
HL1 HL2	Signal light	24V 1.2W	1 1	Handan Machine Electrical Equipment Factory	For CS6266B only.
SB2 SB3 SB4 SB6 SB7	Button Spindle stop Spindle start Spindle start Coolant pump start Coolant pump stop	Ue=380V ~ Ie=5A ? 25 NC+NO red NC+NO green NC+NO green NC+NO green NC+NO red	1	Tianshui 213 Electrical Apparatus Co., Ltd.	
SQ1 SQ2 SQ3	Limit switch	Ue=500V ~ Ie=2A NC+NO	1	Wuxi Machine Tool Electrical Equipment Factory	
EL	Lamp	24V 40W	1	Shanghai Xinhua Luminaire Factory	
TC1	Transformer	1 ~ 50/60Hz 160VA Input 380V/420V/660V Output 220V/110V/24V	1	Wuxi Machine Tool Electrical Equipment Factory	Input voltage is supplied per user's power source.
M1 M2 M3	AC asynchronous motor, Coolant pump 3-phase micro motor	3 ~ 50/60Hz 220V/380V/420V/660V 7.5KW 4P 50L/min 300W/370W	1	Baoji Electric Machine Works Shenyang Micro-machine Factory	Supplied per user's power source

7 Lubrication

Fig. 7-1 is machine lubrication chart.

Machine lubricant CBK68 specified in GB/T 7632—1987 is used as lubricant.




Fig. 7-1 Lubrication chart

7.1 Headstock lubrication

Oil is pumped by the trochoid pump driven by shaft . After being filtered oil is piped to the oil tray and path to lubricate gears, shafts, bearings and etc. in the headstock in a cycle (Fig.7-2).

Always check the pump for good condition by observing through the oil sight glass in front side of headstock. Make sure level of oil is up to the centered line of the oil gauge. Bearing at left end of shaft X is lubricated with No.2 calcium base grease.




Fig. 7-2 Lubrication chart of headstock

7.2 Feeding case lubrication

Parts in feeding case are drop lubricated via some strings of wool soaked with oil stored in oil path in the feeding case (Fig.7-3). Waste oil must be drained off the case according to the indicated mark of the oil sight glass after a period of time.




Fig. 7-3 Feeding case lubrication chart

7.3 Apron lubrication

Oil is reserved in the path of apron. During rapid traverse of apron, all running parts are splash lubricated with oil churned up by the churning fins. Bearings in apron are lubricated either through the cup on carriage into which oil is pressed from an oil gun, or drop lubricated via some strings of wool soaked with oil splashed into the upper groove by churning fins. See Fig. 7-4. Bearings of a right-hand apron are lubricated with oil from the upper groove into which oil is piped by a hand pump. The handle of the pump should be pulled five times before starting to work. See Fig. 7-5.

Observe the level of oil in the oil gauge and make sure it is up to the centered line of the gauge.




Fig.7-4 Apron lubrication chart




Fig. 7-5 Right-hand apron lubrication chart

7.4 Guide ways lubrication

Lower rails of carriage are lubricated by hand pump on the apron though centralized lubrication.

Upper rails of carriage, cross screw, screw of top slide, tool rest, tailstock quill and screw are all lubricated with oil gun.

7.5 Other oil sites

Lead screw, rod and neck of operating rod are drop lubricated by some strings of wool. Oil is stored in the basin of the rear bracket.

The shaft and sleeve of idle pulley in change gears box are greased with No.2 calcium base grease that is pressed into by the plug screw.

8 Coolant unit

Coolant stored somewhere in machine or middle support of machine is pumped up by a three-phase pump AYB-50. Flow of the coolant is regulated with a faucet on the coolant pipe.

9 Lifting, installation and test operation

9.1 Hoisting

When hoisting a crated machine, tie and pass wire ropes per symbols painted on crate. Handle the machine carefully to avoid any bumps or shocks. Keep it up-right and not tilting. Avoid placing the machine over sharp objects.

When hoisting a machine after unpacking, tie and pass wire ropes according to the diagram below (Fig.9-1). Move the carriage back and forth for balance. Place soft substances between the ropes and machine to prevent damage to machine.

9.2 Unpacking

After unpacking, check the machine for good appearance immediately. Check the accessories and tool for correct quantities per PACKING LIST.

9.3 Installation

Though the machine was inspected and tested prior to shipment from the factory it must be installed correctly in order to maintain the accuracy and service life of the machine.

The machine is located by means of several groups of iron wedges on a concrete foundation that is prepared in advance. See Fig. 9-1 foundation plan. Level the machine using precision levels to within the accuracy of 0.06/1000 in lengthwise direction and 0.03/1000 in width-wise direction by adjusting the jack bolts. After primary adjustments are finished, pour mortar into holes for anchor bolts. Minute adjustments are to be done only after the mortar is hardened completely. When the machine is leveled to the required accuracy give every bolt nut an even screw, pour mortar to iron wedges and on the machine base leaving a smooth face of foundation.

9.4 Cleaning

The anti-rust agent applied on machine must be thoroughly removed with kerosene. Inside of headstock should be cleaned with warm kerosene. All strings of wool must be cleaned also. After completion of cleaning, fill sufficient oil to machine according to the lubrication chart.

9.5 Test operation

Before test operation carefully read the OPERATOR'S MANUAL to learn the function and use of every control and be sure the machine is properly lubricated.

Operate every operating part by hand for good condition.

Before turning on the electric power of machine, make sure the electrical unit is in good condition and the motor doesn't suffer from damp. After turning on the electric power, check that the motor is rotating clockwise. Otherwise wiring of phase lines must be rectified.

Dry run is performed only after all the above procedures are completed. Operate the machine first at the minimum speed for a period of time and gradually increase the speed. Carefully observe working condition of the lubrication unit, operation unit, electrical unit, cooling unit and other functioning unit during dry run.

Do not start to work unless the machine is operable, properly lubricated and braked freely with a normal functioning of controls.




Fig.9-1 Lifting and foundation plan

10 Maintenance and care

10.1 Lubrication

In order to keep good operation and reduce wear, all running and sliding parts on the machine must be properly lubricated periodically. So pay special attention to the following points.

- a) Fill clean oil at regular intervals according to the lubrication chart.
- b) Each of headstock, apron and feeding case should be filled with oil up to the centered line of their oil gauges. Take care that oil level should not be higher than the upper line of each gauge. Oil will overflow in that case. So it is important to check oil level from time to time and keep it in correct position.
- c) Because of serous wear on a new machine first change of oil both in headstock and apron should occur ten days after using of machine and second change twenty days after, thereafter it is replaced every two or three months in order to keep the headstock and apron clean all the time. After the waste is drained out the headstock and apron must be washed with kerosene.
- d) The filter in headstock and strings of wool on the machine must be cleaned every month. Dustproof scrapers at ends of lower rails of carriage and that at left side of tailstock's bottom must be cleaned every week with kerosene. Replace the felts when they are worn.

10.2 Operation

Pay attention to the following points when operating the machine.

- a) After the main motor is started, the spindle is started only when the lube pump is confirmed in good condition and sufficient oil is confirmed in the headstock.
- b) Never change speed while the spindle is running at a high speed. Change it only when the spindle is stopped. Feed rate is changed either when the spindle is stopped or running at a lower speed.
- c) Before starting the spindle make sure that every gear-shifting lever is in a correct position to ensure good engagement between gears.
- d) When the brake fails to work repair it immediately. Never use the reversing friction clutch as a brake.
- e) When operating any of the spindle control levers be sure to place it downward or upward completely. Un-complete operation is not allowed for decreasing the speed during cutting.

10.3 Maintenance

In order to maintain the accuracy and service life of every part on the machine, take note of the following points.

- a) Check and adjust the tension of V-belts periodically to maintain its service life.
- b) Clean any dirt or waste coolant deposited between the four-way tool post and its slide to keep **repeatability of the slide**.
- c) If the tailstock is used to support the workpiece for cutting, a Morse Taper No. 5 tang must be applied and horizontally inserted into the hole of tailstock quill so that it engages with the stop dog, which can prevent the tang from rotating and maintain the accuracy of the taper hole.
- d) The lead screw is designed for cutting threads not for longitudinal feeding of work piece. Feeding might affect the service life and accuracy of lead screw. Since the apron is driven directly by the lead screw when threading the safety clutch in apron become useless. Take care to choose a proper depth of cut and a proper cutting force P_x not larger than 3500N.
- e) Long and slender shaft-type work should be turned using a steady rest or follow rest. Lubricate the bearing face of work before starting.
- f) Be sure to stop the main motor prior to workpiece loading/unloading or before the operator leaves.

11 Adjustment and structure

11.1 Machine bed

The main motor and coolant pump are located in the machine front support and back support respectively. Coolant pump is located in the middle support for a machine over 2 meters. Electric switchboard is located in the window at rear side of the machine. The tension of drive belts must be properly adjusted with the adjusting nuts. See Fig. 11-1.

High grade hardened cast bed ways ensure high rigidity and maintenance of accuracy in a long time.




Fig. 11-1 Drive belt adjustment diagram

11.2 Headstock

This is an all-gear centralized drive headstock. Power from the main motor is transmitted through V-belts to shaft which drives the spindle by means of multiple-plate friction clutch and several steps of gears. Direction of spindle rotation is determined by the friction clutch. In order to ensure smooth running of spindle the friction clutch must be properly adjusted. It is not allowed to be too tight or too loose. Being too loose may cause not only ineffectiveness and non-sufficient output of spindle power but also frequent slip and heat that will result in serious wear. Being too tight may make it difficult to operate thus losing function of protection. See Fig. 11-2.




Fig. 11-2 Multiple plate friction clutch adjustment diagram

The brake is used to control the spindle rotation instead of the clutch when clutch is out of engagement. If the

spindle fails to come to a dead stop the brake band needs to be tightened with the adjusting nuts. Care not to twist the band. See Fig. 11-3.




Fig. 11-3 Brake band adjustment diagram

The spindle is supported on three bearings of which the front and middle bearings offer main support and rear bearing offers assistant support.

In order to ensure the machining accuracy and cutting ability of the machine, play of spindle must be adjusted carefully till radial run-out and axial slip are exactly as the machine requires (See Fig.11-4).

When it is necessary to adjust the spindle bearings, loosen nut (1) and nut (2). Be sure to remove the stop washer prior to loosening nut (2). Adjust the spindle front bearing with nut (3) and middle bearing with nut (4) till a proper play is reached. Finally tighten every nut again.

After completion of the above procedure, dry run of over one hour must be performed for the spindle. The temperature of spindle in steady state should be no more than 70 °C, otherwise readjustment must be made.

In order to keep balance and avoid vibration at non-load, a balancer is fixed to gear (5) of spindle. Every machine undergoes a balance check prior to shipment from the factory. If it is balanced no balancer is fixed.

Torque from gear-shifting mechanical is transferred with a chain. The chain may stretch after a long use and cause the speed plate to give an improper or wrong value. So it must be adjusted to tension by means of the adjusting screws. See Fig. 11-5.




Fig.11-4 Spindle bearing adjustment




Fig. 11-5 Chain tension adjustment diagram

11.3 Tailstock

A stop dog (6) fixed in the taper hole of the tailstock is to prevent the tool held from rotating. The tailstock can move crosswise on the single-direction ways. Cross adjustment is performed with screw (1). Before adjusting be sure to unclamp the tailstock and loosen the screw (2). After completion of adjustment tighten screw (2) again. When resetting the tailstock, make sure that flanges (8) are in alignment. See Fig. 11-6.

The tailstock can move on the bed ways and be clamped and locked in position with the eccentric shaft. The clamping force is adjusted with nut (3) and (4). When tailstock is heavily loaded nut (5) is used to clamp it as well as the eccentric shaft.

When the clamping lever is released the tailstock is supported on four rolling bearings with spring seats, clear of bed ways. That makes it an ease for the tailstock to move along the bed ways. The clearance between tailstock and bed ways is adjusted with screw (7). Before adjusting the tailstock should be locked to ensure proper contact between tailstock and bed ways and prevent bearings from being broken.




Fig. 11-6 Tailstock adjustment diagram

11.4 Carriage

The cross slide is driven by the split nut which moves with rotation of lead screw and is used to eliminate transmission clearance by adjusting the pitch diameter fit. When adjusting loosen the stop screw (2) first and then adjust screw (1) till the clearance is removed. After completion tighten screw (2) again and cover the dust lid (3). See Fig.11-7.

If the sliding ways of cross slide and compound rest have too large clearance or they are hard to move, adjust the clearance with the adjusting screws at ends of the rack strip.




Fig.11-7 Cross slide screw nut adjustment diagram

11.5 Apron

The apron controls feeding movements of carriage. Drive from the rod is transmitted to the apron, which in turn drives the carriage to move longitudinally or crosswise by means of safety clutch, worm and transmission gears.

In order to make it possible for the carriage to perform rapid traverse at any time the worm is fixed with a one-way overrunning clutch that overpasses the drive from the rod when the rapid traverse motor is driving the worm in a selected direction.

When the carriage is moving in rapid traverse mode or auto feeding mode the apron handwheel is disengaged for safety and it is engaged again after the carriage stops.

If the cutting force is always below the maximum permissible cutting force of the machine, the safety clutch needs to be adjusted with screw (2). Before adjusting, be sure to remove the cover (1). See Fig. 11-8. Care not to over tighten the clutch. An over tight clutch may lose the function of protection and cause damage to machine parts.

To prevent simultaneous engagement of rod and lead screw an interlock mechanism is fixed between the split nut and the operating shaft.




Fig.11-8 Safety clutch adjustment diagram

11.6 Feeding case

In the feeding case there are sliding gears mounted on three shafts, thread selecting mechanism and multiplying mechanism, so normal threads are cut without changing gears.

In order to cut high accuracy threads and eliminate the axial slip of lead screw the anti-thrust bearing (2 and 3)

must be adjusted with nut (1). See Fig. 11-9.





Fig.11-9 Screw shaft anti-thrust bearing adjustment diagram

11.7 Change gearbox

Multiple threads of 2,3,4,5,6,10,12,15,20,30,60 are cut on the machine thread by thread without having to change gears. Change gears only when cutting 19 tpi and 11 1/2 tpi threads. See Fig. 11-10, those in parenthesis represent inch gears. Loosen and remove idle gear shaft (3) together with nut (2), exchange with new gears, put shaft (3) and nut (2) back again and tighten them. Loosen nut (1). Make some adjustment till a proper engagement with the gear just replaced on shaft is got. Tighten nut (1) again. See Fig. 11-10.



CS6140 series

CS6150 series




Fig.11-10a Diagram of engagement of change gears




Fig. 11-10b Engagement of change gears of CS6266B

11.8 Chuck, Driving plate and Spindle nose

11.8.1 Chuck, driving plate and spindle nose of CS6140 series

Chuck or driving plate is mounted and connected onto the spindle by a short taper flange. When mounted 4 nuts (1) should be tightened equably.

When removing the chuck or driving plate from the spindle nose, loosen nut (1) and 2 screws (2), and keep rotating retainer ring (3).

No matter whether chuck or driving plate is used 2 screws (2) should be tightened completely. Otherwise they may make noise during spindle rotation. The six cams with a key aligning reference line 1 with reference line 2.

See Fig. 11-11 for structure of spindle nose.

11.8.2 Chuck, driving plate and spindle nose of CS6140B series

Chuck or driving plate is mounted and connected onto the spindle by a short taper cam lock.

When mounting, align reference line 2 on cam (4) with reference line 1 on spindle nose; align reference line 3 on studs of chuck or driving plate with left face of chuck or driving plate; tighten them with screw (6). Insert six studs of chuck or driving plate into six holes in spindle nose and turn the six cams with the square key supplied till they are locked.

When removing the chuck or driving plate from the spindle nose, loosen the six cams with a key aligning reference line 1 with reference line 2. A face plate is mounted onto or removed from the spindle nose in the same way as the chuck or driving plate.

See Fig. 11-12 for structure of spindle nose.




Fig. 11-11a Mounting of chuck or driving plate onto spindle ISO702/ No.6




Fig. 11-11b Structure of spindle nose ISO702/ No.6




Fig. 11-12a Mounting of chuck or driving plate onto spindle ISO702/ No.8

12 Wear parts of the machine and their machining diagrams


Table 12-1 List of Wear Parts


Part No.	Name	Material	Heat treatment	Qty	Remark
02041	Bushing	ZcuSn10Pb1		2	
02136	Lever	45	Local G48	1	
02192	Friction plate	15	S0.5-C60	14	
02193	Friction plate	15	S0.5-C60	16	
02194	Brake band	65Mn		1	
02211	Outer roller of trochoid pump	Iron base powder		1	
02212	Inner roller of trochoid pump	Iron base powder		1	
02231	Brake friction plate	Iron sand canvas		1	
05011	Nut	ZcuSn10Pb1		1	05011Y Inch parts)
06021	Worm	ZcuSn10Pb1		1	
06022	Half nut	ZcuSn10Pb1		1	06022Y Inch parts)
08011	Spline collar	ZcuSn10Pb1		1	
GB83-85	ScrewM16×40	35		8	
	Center 5 [#]	T8	C58	2	

فروشگاه کانون ابزار

all5.ir

021 66393900 = 0912 1473023






Part No. : 02136

Name : Lever

Material : 45

Quantity : 1




Sand blast S0.5-C60

Part No.: 02192

Name : Friction plate

Material: 15


Quantity: 14




Sand blast S0.5-C60

Part No.: 02193
 Name : Friction plate
 Material: 15
 Quantity: 16

Unless otherwise specified ✓




Part No.: 02194
 Name : Friction plate
 Material: 65Mn
 Quantity: 1




Generated radius = 16.95

Part No.: 02211
 Name : Outer rotor of trochoid pump
 Material: Power metallurgy
 Quantity: 1



Generated radius = 16.95



Part No.: 02212
 Name : Inner rotor of trochoid pump
 Material: Power metallurgy
 Quantity: 1



A-A


Cut and leave a straight smooth edge

Part No.: 02231
 Name : Brake friction plate
 Material: Iron sand cancas
 Quantity: 1



Worm type	Archimedes	Axial profile angle of worm s	20 °
Axial modulus of worm ms	2.5	Teeth number of wormwheel Z2	26
Number of starts of worm	2	Position change ratio of wormwheel	0
Helix angle and rotary direction of worm	Left-hand 6°20 25	Machining accuracy	8DC


Part No.: 06021
 Name : Wormwheel
 Material: ZCuSn10Pb1
 Quantity: 1



Unless otherwise specified. $12.5 \sqrt{\quad}$


T40x12-8(metric)
T40x12.7-8(inch)
A=6 (metric)
A=6.35 (inch)

Part No. 06022(metric)
06022Y(inch)
Name Split nut
Material ZCuSn10Pb1
Qty. 1




Unless otherwise specified. $12.5 \sqrt{\quad}$

Part No. 08011
Name Splined bush
Material ZCuSn10Pb1
Qty. 1



Surface
oxidization

Code	GB83-88
Speci.	M16x40
Name	Screw
Material	35
Qty.	8



Unless otherwise
specified.

Heat treatment C58

Speci.	MT No.5
Name	Center
Material	T8
Qty.	2

13 Standard accessories, tools and optional accessories

Table.13-1 Standard accessories

Part No.	Name	Specification	Qty.	Remarks
09100	3-jaw chuck and adapter	? 250/? 315	1 set	For CS6140/CS6266B lathes
09100A	3-jaw chuck and adapter	? 250	1 set	For CS6266B lathes
S77-1	Center	Morse taper 5	2 set	
S76-1	Center sleeve	Morse taper 6/5	1 set	For CS6140 lathes
12003	Center sleeve	? 90 ; 1 : 20/5	1 set	For CS6140B lathes
	Mounting pad	(for domestic market only)	6 set	8 sets for 2M, 2.5M,3M lathe

Table 13-2 Tools

Part No.	Name	Specification	Qty.	Remarks
S92-3	Square socket wrench	17	1 set	For setting the cutters.
12001	Allen key	12	1 set	For setting cams of spindle on B lathes
S93-1	Hook spanner	45-52	1	For setting lead screw
S93-1	Hook spanner	115-130	1	For setting spindle bearings (Not for B series)
S93-1	Hook spanner	150-160	1	For setting spindle bearings on Blathes
GB1165-74	Oil gun	100 cm ³	1	

Table 13-3 Optional accessories

Part No.	Name	Specification	Qty.	Remarks
09200	Drive plate	? 250	1 set	For CS6140 lathes
09200A	Drive plate	? 250	1 set	For CS6140B lathes
09400	Face plate	? 630	1 set	For CS6140 lathes
09400A	Face plate	? 630	1 set	For CS6140B lathes
09100B	4-jaw and adapter	? 400	1 set	For CS6140 lathes
09300B	4-jaw and adapter	? 400	1 set	For CS6140B lathes
10100	Steady rest	? 20-? 125	1 set	
10200	Following rest	? 20-? 80	1 set	
10300	Super-giant steady rest	? 120-? 220	1 set	
12002	Pin remover	M12	1 set	For gap-bed lathes
01035	Full-length splash guard		1 set	750/1000/1500/2000
66B09400	4-jaw and adapter	? 500	1 set	For CS6266B lathes

10300	Super-giant steady rest	? 120-? 260	1 set	For CS6266B lathes
16000	Full-length foot brake	750/1000/1500/2000	1 set	
17000	Long. feed auto stop		1 set	
17000	Cross feed auto stop		1 set	
	Digital readout		1 set	Crosswise coordinate
09700	Long. 1-position stopper		1 set	
09600	Long. 4-position stopper		1 set	
66B 03000	Double-speed tailstock		1 set	For CS6266B lathes
50C 11000	External lubrication		1 set	For CS6266B lathes
09800	T-shaped tool post		1 set	
09900	Thread chasing dial (metric/inch)	12 (1?)	1 set	
13000	Taper turning attachment	$\pm 10^\circ$	1 set	
02300	Chuck cover	? 250 chuck		
22400	Tool post cover		1 set	
19500	Face plate	? 710	1 set	For CS6266B lathes
19600	Face plate	? 800	1 set	For CS6266B lathes
225000	Lead screw guard		1 set	For 750/1000 lathe
226000	Triple rod guard			For 1500/2000 lathe
66B 223000	Chuck cover	? 315 chuck		For CS6266B lathes

14 Foot brake

14.1 Application and function

This brake is designed for stopping the high running main motor and other transmission units of machine. It is simply constructed, efficient, independent and easy to service.

14.2 Structure and working principle

Fig.14-1 shows the structure of the foot brake. It consists of pedal, connection rod, support, seat, cam, strain arm, pulley, steel band, braking assembly and electrical unit. As soon as the pedal (6) is trodden, cam (15) will disconnected the over-travel limit switch (16) with the help of strain arm (14), cut off the power to main motor. The motor is thus stopped under the combined action of strain arm (14) and steel band (11).

The spindle is unable to re-start unless the starting lever (10) is set to NEUTRAL position.

14.3 Electric unit

Fig. 6-2a is electric schematic diagram of CS6140 series equipped with foot brake and Fig. 6-3a is electric connection diagram. Fig. 6-2b is electric schematic diagram of CS6266B and Fig. 6-3b is electric connection diagram of CS6266B.

14.3.1 For electrical unit of foot brake, please refer to section 6 electrical part of the machine.

The main motor of machine can't be started unless the starting lever is set to NEUTRAL position. See Fig.14-1.

When the starting lever (10) is set to NEUTRAL position, dog (17) operates and close SQ3 of limit switch (18). In this case the contactor is closed when SB3 or SB4 (KM1) is depressed, and the main motor is operatable.

When it is necessary to stop the rotating spindle, step on pedal (7) and the limit switch (16) SQ2 is switched off, meanwhile the main motor is disconnected to a stop. The main motor can also be stopped by depressing SB2 or SB5 and it can not be restarted unless the starting lever is set to NEUTRAL position.

During turning operation control circuit can be disconnected by depressing SB5 in a case of emergency.

14.3.2 Adjustmen

When starting lever is set to NEUTRAL position, dog (17) should be adjusted so that SQ3 of limit switch (18) is in a compressed state. Some adjustment should be made so that limit switch (16) SQ2 is in released state when no pedal is stepped and in compressed state when pedal is stepped.

See Table 6-1 for electric components.

14.4 Set up

The swivel angle of pedal (7) is changed by adjusting the length of steel band (11) using the nut of tightening screw rod (12). The height of pedal (7) is changed after loosing the pressure rod (8). The pedal must be locked again after adjustment. Cam (15) is adjusted so that the machine brakes to a steady stop when limit switch (16) is switched off. Limit switch (18) should be adjusted so that it is closed prior to starting of spindle.


14.5 Easy-worn parts

See table 14-1 for easy-worn parts.


Following is a diagram of machining the easy-worn parts. (B16008, B16010)

Table 14-1 List of easy-worn parts

Draw No.	Name	Material	Heat treatment	Qty.	Remark
B16008	Steel band	65Mn	C42	1	
B16010	Braking band	Wire asbestos band		1	



C42
B16008




B16010

فروشگاه کانون ابزار

all5.ir

021 6639 3900 - 0912 147 3023



Note: Operator's panel of CS6140 series lathe is located on change gear cover. That of CS6266B is located on headstock.

Open in K direction.




Fig.14-1 Structure of foot brake

- | | | |
|--|-------------------------|-----------------------------------|
| 1 Emergency stop, spindle start button | 8 Pressure rod | 16 Limit switch |
| 2 Power switch | 9 Connection rod | 17 Dog |
| 3 Pin | 10 Starting lever | 18 Limit switch |
| 4 Left support | 11 Steel band | 19 Coolant pump start/stop button |
| 5 Tension spring arm | 12 Tightening screw rod | 20 Spindle start/ stop button |
| 6 Tension spring | 13 Upper seat | |
| 7 Pedal | 14 Strain arm | |
| | 15 Cam | |

15 Taper turning attachment

15.1 Application

This attachment is designed for taper turning and taper pipe threading. It is a special accessory of CS6140 series lathe produced in our factory.

15.2 Main specifications

Max. taper turning length : 220mm

Swivel angle : $\pm 12^\circ$

Max. travel : 20mm

15.3 Structure

See Fig.15-1.




Fig. 15-1 Structure of taper turning attachment

The attachment is fixed to machine as shown in Fig. 14-1. Support (1) is fastened to rear face of machine

saddle (2) with 2-M6 screws and 2-10 taper pins. Bracket (9) is fastened to machine bed (10) with taper pins. When operating, I-shaped sliding block (3) moves along plate (4) and sliding slot (5) moves along scale (6) that is connected with graduation plate (7) with taper pins.

15.4 Setting up

Before using, the scale, which swings back and forth in the graduation plate around the shaft pin, must be properly adjusted so that it points to correct graduation mark as required by the work piece to be turned. Rotate the adjusting screw arbor till the scale is pointed in position, and fasten it to the graduation plate with two T-slot screws. During operation the tool will move a taper path, thus a taper is turned. During taper turning some length of cylindrical surface is always cut due to mechanical backlash. So it is necessary to take a test operation to find the length (it varies with different taper work pieces). After setting up the tool, true turning cannot be taken unless the said length is eliminated by moving the carriage a same distance to the right using the apron handwheel.

15.5 Caution

When the taper turning attachment is not to be used, bracket (8) must be removed. Some adjustment should be made so that the scale is pointed to zero. Fasten T-slot screws (12) and lock I-shaped sliding block (3) using two pointless set screws (13) to stop the drive screw from sliding back and forth.

When it is necessary to check the terminal block for trouble removing, take off the taper turning attachment first.

Every running parts of the attachment should be lubricated with an oil gun every shift of work to reduce wear and guarantee operation.

16 Mechanical Feed Stop

The machine is designed with a mechanical feed stop, which automatically stops the longitudinal and crosswise feed motion of carriage at a desired position.

During feeding, the carriage stops at the position where a dog is pre-set. That is, the lever located in apron, once come into contact with the dog will disengage the jaw clutch mounted on worm shaft in apron. The jaw clutch in turn will stop the carriage.

Six adjustable dogs, mounted on the positioning rod that is fixed with machine bed, are used to stop the longitudinal feed.

Note: The mechanical feed stop is ineffective during rapid traverse motion of carriage.

This manual is subject to change without notice due to continuous improvement of products.

فروشگاه کانون ابزار
all5.ir

021 66393900 - 0912 1473023